


ATTENTION! KEEP THIS MANUAL FOR FUTURE REFERENCE!

**INSTRUCTION MANUAL FOR USE OF
BABY TWIN STROLLER
“2 CLASSY”**

2 CLASSY



This stroller **chipolino** has been manufactured in accordance with the Product Safety Directive 2001/95/EU of the European Parliament and The Council and with European standard EN 1888-1 “Child care articles. Wheeled child conveyances. Part 1: Baby strollers and carry cot”, EN 1888-2 “Child care articles. Wheeled child conveyances. Part 2: baby strollers for children from 15 kg to 22 kg” and EN 1466: 2014 “Child care articles. Carry cots and stands. Safety requirements and test methods” and the regulations of national law, including Consumer Protection Law.

FOLLOW ALL WARNINGS, INSTRUCTIONS AND RECCOMENDATIONS IN THIS MANUAL IN ORDER TO GUARANTEE THE SAFE USE OF THIS PRODUCT!

CAUTION! WARNINGS!


- ❖ NEVER LEAVE YOUR CHILDREN UNATTENDED!
 - ❖ FOR NEWBORN BABIES THE MOST LYING POSITION OF THE BACKRESTS IS RECOMMENDED!
 - ❖ THE SITTING POSITION OF THE RECLINING SEATS IS TO BE USED ONLY FOR A CHILDREN AT LEAST 6 MONTHS OLD!
 - ❖ KEEP AWAY FROM FIRE!
 - ❖ DO NOT LIFT THE STROLLER BY ITS FRONT BUMPER!
 - ❖ ALWAYS USE THE SAFETY BELTS ONCE THE CHILDREN CAN SIT UNAIDED!
 - ❖ MAKE SURE ALL PARKING DEVICES ARE ENGAGED BEFORE USE.
 - ❖ IN ORDER TO AVOID INJURY, MAKE SURE CHILDREN ARE AT SAFE DISTANCE FROM THE STROLLER DURING ITS ADJUSTING, UNFOLDING OR FOLDING!
 - ❖ DO NOT ALLOW YOUR CHILDREN TO PLAY WITH THE STROLLER!
 - ❖ THIS PRODUCT IS NOT SUITABLE FOR RUNNIG OR SKATING!
-
- ❖ Use the stroller for children weighing not more than 22 kgs per child.
 - ❖ Adult assembly is required!
 - ❖ Do not put additional mattresses in the seats!
 - ❖ Always activate the parking device when you put the children in or out of the stroller!
 - ❖ Make sure the safety belts are correctly fastened and adjusted before each use.
 - ❖ The maximum load for the storage basket is 3 kg per basket!
 - ❖ The maximum load of the diaper bag is up to 2 kg!
 - ❖ Do not overload the stroller! Every load attached to the handle, bumper, and backrest or on the side of the stroller will affect its stability!
 - ❖ This stroller is suitable for two children.
 - ❖ Only use spare parts or other components, which are recommended or supplied by the producer! In the contrary case the producer is not responsible for the product's safety.
 - ❖ Do not make any changes or modifications to the stroller's construction! In case of problems contact the dealer or an authorized repair service for advice and/or repair.
 - ❖ Do not use this stroller if you find missing or damaged parts!
 - ❖ Do not allow children younger than 3 years near the stroller during its assembly!
 - ❖ Do not attach any strings or long cords to the stroller in order to avoid risk of suffocation!
 - ❖ Do not use the stroller on stairs or escalators and pay attention when overcoming a curb or a step.
 - ❖ Keep the plastic packaging away from children in order to avoid risk of suffocation!



MAIN FEATURES

- ❖ This stroller is suitable for two newborn babies or children aged up to 4 years or weighing up to 22 kgs per child (whichever comes first);
- ❖ 5-point safety harness;
- ❖ Adjustable backrests;
- ❖ Adjustable canopies;
- ❖ Adjustable leg rests;
- ❖ Straight and swivel motion of the front wheels

MAIN PARTS DIAGRAM



1. Handle
2. Canopy
3. Safety bumper
4. Upholstery
5. Front wheel
6. Leg rest
7. Safety belt
8. Folding button

ASSEMBLY INSTRUCTIONS AND FUNCTIONS

This stroller is supplied partially assembled. In order to complete the assembly, you don't need any tools.

IMPORTANT! Follow exactly the instructions given and check the pictures. Keep your hands from entrapment!

IMPORTANT! After each operation, make sure that you have followed the instructions correctly and the fixing is stable!

IMPORTANT! In most cases after the completion of an operation you will hear a clicking sound.

The assembly, disassembly and functions are numbered from 1 to 9. Use the operations descriptions given in this manual and their matching picture.

1 – UNFOLDING THE STROLLER

2 – FRONT WHEELS

2-1 Installation and removal

In order to remove the front wheels, press the removal button and take them out.

2-2 Straight and swivel motion

Note: When you move the stroller on uneven surfaces, it is recommended to fix the wheels in straight motion.

3 – REAR WHEELS

3-1 Installation and removal

3-2 Parking device

IMPORTANT! Always apply the parking devices while stroller is not in motion to avoid sudden sliding and injuries!

4 – SAFETY BUMPERS

4-1 – Attaching the safety bumper

4-2 – Removing the safety bumper

Press the buttons on both sides of bumper and remove it.

5 – CANOPIES

CAUTION! Always attach the canopies at the back of the seats in order to prevent the children from sliding off and injury.

6 – ADJUSTING THE BACKRESTS RECLINE POSITIONS

6 (1) – Press the backrest adjusting button;

6 (2) – Move the mechanism:

- Up – to lower the backrest position;
- Down – to move the backrest to more sitting position.

7 – LEG REST

- Adjustment in lower position – press the buttons on both sides of leg rest and move it down;
- Adjustment from lower position to flat position – push each leg rest up with your hand.

8 – RESTRAINT SYSTEM (SAFETY BELT)

A – central buckle

To unfasten the safety belt, press the central buckle and split the belts.

Insert the shoulder belts ends in the central buckle and press until you hear a **click**.

Adjust the shoulder and waist belts length by the sliders (**B**).

CAUTION! Belts must be snug to children's bodies and must not be twisted.

IMPORTANT! Periodically check to ensure that the seat belt is securely attached to the stroller frame as well as securely fastened. The seat belt straps must not be damaged, worn out or twisted!

CAUTION! Babies aged under 6 months must be put in the stroller only when seats' backrests are in most lying position! Before you place the babies in the seats, remove the shoulder safety belts or toss them to the seats' sides and cover the seats with thin soft pad!

9 – FOLDING THE STROLLER






IMPORTANT! Before folding the stroller the paring device must be engaged and the storage basket should be empty.








9-1 – Close the canopies;

9-2 – Press simultaneously the second lock mechanism and the folding button;

9-3 – Press the handle down until stroller is folded;

9-4 – Attach the transport hook to keep the stroller folded.





CARE AND MAINTENANCE GUIDELINES

- ❖ The brakes and wheels wear out faster than other parts. Replace them when necessary.
- ❖ Regularly oil the moving parts. Use silicone oil or silicone spray for oiling.
- ❖ Clean and oil all dirty metal and plastic parts regularly.
- ❖ Clean the fabrics, plastic parts and metal parts with damp cotton cloth or sponge and mild soap.
- ❖ Do not use aggressive detergents, solvents, bleach or spirits to clean your stroller.
- ❖ Always leave the stroller to fully dry after cleaning before you use it or store it. Mold could form if you keep your stroller moist.
- ❖ Always store your stroller indoors in clean and dry place. Do not expose to direct environment influence - sun, rain, moisture and high temperature intervals.
- ❖ Please, contact your authorized dealer for problems connected with the use or repair of this stroller.

Fabric Composition:

Outer: 100% Polyester

Filling: 100% Polyester



KBCL0210xxx

CHIPOLINO

Bulgaria, Plovdiv, str. Golyamokonarsko shosse 1

www.chipolino.com