


**IMPORTANT! PLEASE READ CAREFULLY THIS INSTRUCTION MANUAL
AND KEEP IT IN A SAFE PLACE FOR FUTURE REFERENCE!**

**INSTRUCTION MANUAL FOR
KIDS' TOY 2 in 1 – SCOOTER - RIDE ON
„X-PRESS”**

X-PRESS




This product **chipolino** is produced in accordance with requirements of Toy safety Directive 2009/48/EC of the European Parliament and the Council, Regulation regarding Essential Requirements and Conformity Assessment of Toys, Regulation regarding Conformity Marking and the standards applicable for this toy.

**FOLLOW ALL WARNINGS, INSTRUCTIONS AND RECOMMENDATIONS IN THIS
MANUAL IN ORDER TO GUARANTEE THE SAFE USE OF THIS PRODUCT:**

CAUTION! WARNINGS!

- ❖ **CAUTION!** USE ONLY UNDER DIRECT ADULT SUPERVISION – FALLING DANGER!
- ❖ **CAUTION!** THIS TOY IS SUITABLE FOR CHILDREN AGED 1 YEAR AND UP AND WITH WEIGHT UP TO 20 KG WHEN USING AS A RIDE ON (WITH SEAT) AND 50 KG WHEN USING AS A SCOOTER!
- ❖ **CAUTION!** DO NOT OVERLOAD THE TOY! IT IS NOT FOR CHILDREN WEIGHING MORE THAN 20 KG WHEN USING AS A RIDE ON (WITH SEAT) AND 50 KG WHEN USING AS A SCOOTER!
- ❖ **CAUTION!** BEFORE USING THE PRODUCT, TEACH THE CHILD THE CORRECT WAY TO USE IT AND THE SAFETY RULES. Some special skills are required for riding this toy and it should be used with high attention to avoid impacts, falling and injuries.
- ❖ **CAUTION!** CHILD MUST WEAR PERSONAL PROTECTOR WHILE RIDING THIS TOY – helmet, elbow and knee protectors, suitable shoes.
- ❖ **CAUTION!** BEFORE USAGE ALWAYS CHECK IF THE STEERING BAR IS SECURELY FIXED TO THE FRAME AND ALL FASTENERS (SCREWS, BOLTS, NUTS) ARE WELL TIGHTEN.
- ❖ **CAUTION!** USE THE TOY ONLY DURING THE DAY ON EVEN PLAYGROUNDS AND AT A SAFE DISTANCE FROM STREETS OR ROAD LANES FOR VEHICLES.
- ❖ **CAUTION!** KEEP AWAY FROM FIRE OR OTHER HEAT SOURCES!
- ❖ **CAUTION!** USE THE TOY ONLY FOR ITS PURPOSE.
- ❖ **CAUTION!** THIS TOY IS NOT FOR INTENDED FOR AGGRESSIVE RIDING, TRICKS AND JUMPS.
- ❖ **ONLY** adult assembly of the TOY is required!
- ❖ **DO NOT** allow presence of children under 3 years before assembly of the TOY is complete. In this way, you will avoid their access to small or loose parts!
- ❖ The TOY is intended for one child at a time **ONLY!**
- ❖ **DO NOT** use the TOY if you find missing or damaged parts.
- ❖ The brake **MUST NOT** be used while turning left or right, because child can fall and injure.
- ❖ **DO NOT** tie strings or accessories to the TOY in order to avoid the risk of suffocation.
- ❖ **DO NOT** put items or luggage in the steering bar to avoid risk of injury resulting from the TOY's instability and tipping over!
- ❖ **CAUTION!** Child must keep the steering bar with both hands to be able to ride stable and safe.
- ❖ **DO NOT** place items or heavy objects in the TOY or on it during storage or transportation to avoid damage to the frame.
- ❖ **DO NOT** use another transport means to move the TOY by pulling it.
- ❖ **DO NOT** allow the child, who is using the TOY or other children around it to touch the wheels or put items in them.
- ❖ Use away from rivers, pools, stairs or hurdles!
- ❖ **DO NOT** make changes or modifications to the TOY frame! If necessary, contact the retailer or an authorized service center for advice and repair.
- ❖ Use only spare parts, which are approved by the producer and recommended by the distributor or company service! The producer revokes all responsibility in case parts different from the original ones have been used.
- ❖ Keep nylon packages away from children to avoid risk of suffocation!

CAUTION!




PRODUCT FEATURES

- ❖ TOY is suitable for children older than 1 year with weight:
 - up to 20 kg when using the toy as a ride on (with seat);
 - up to 50 kg when using the toy as a scooter;
- ❖ TOY can be used as a **ride on** or **scooter**
- ❖ **SCOOTER** – Child grasps the steering bar with both hands, place one of his/her feet on board and pushes the toy with the other one.
- ❖ **RIDE ON** - Child sits on the seat, grasps the steering bar with both hands and push the toy with his/her feet.
- ❖ Rubber grips at the steering bar with protector to prevent sliding of the hands.
- ❖ Brakes on rear wheel.

MAIN PARTS

Please, make sure if all these described parts are available in the package:



ASSEMBLY INSTRUCTIONS

CAUTION! FOLLOW EXACTLY THE INSTRUCTIONS GIVEN FOR ASSEMBLY AND USAGE OF THE TOY AND CHECK THE PICTURES.

CAUTION! AFTER EACH OPERATION, MAKE SURE THAT YOU HAVE FOLLOWED THE INSTRUCTIONS CORRECTLY AND THE FIXING IS STABLE!

CAUTION! TOY MUST BE USED WITH HIGH ATTENTION BECAUSE BALANCE SKILLS ARE REQUIRED. ONLY THIS WAY YOU WILL AVOID FALLING OR IMPACTS CAUSING INJURIES OF THE CHILD.

For assembly of the toy you do not need any tools.

RIDE ON TOY



1 – SEAT ASSEMBLY

Place the seat into the opening at the frame and fix with the screw.

2 – STEERING BAT ASSEMBLY AND REMOVAL

Assembly: Place the steering bar into the opening at the seat and press until you hear a click sound

Removal: Press the buttons for quick release and remove the steering bar from the seat.



SCOOTER



3 – SEAT ASSEMBLY

Place the seat vertically into the opening at the frame and fix with the screw.



4 – STEERING BAR ASSEMBLY AND REMOVAL

Assembly: Place the steering bar into the opening at the seat and press until you hear a click sound

Removal: Press the buttons for quick release and remove the steering bar from the seat.



5. STEERING AND BRAKE



5-1. TURN LEFT AND RIGHT.

Press simultaneously both side buttons (1) and pull down the lever (2).

5-2. STRAIGHT MOTION.

Press simultaneously both side buttons (1) and pull up the lever (2).


On rear wheel of scooter there is a **brake**. To activate the brake while riding, child must step with his/her heel and press it until scooter stops.

CAUTION! Brake must be used only with one foot.

Using of helmet, knee and elbow protectors, shoes

For better safety during riding child should wear a helmet, knee and elbow protectors and appropriate shoes!

The helmet must be steady on the head, not tilted back or in position in which it does not protect the forehead.



MAINTENANCE GUIDELINES

- ❖ Periodically check the good working order of all parts.
- ❖ Do not wash the TOY and do not soak the TOY in water. Use a soft damp cloth and water or neutral liquid detergent.
- ❖ Do not use aggressive detergents, containing abrasive particles, ammonia, bleach or spirits.
- ❖ Regularly oil the moving parts.
- ❖ Do not use on sand.
- ❖ Do not store the TOY in hot environment or near strong sources of heat, in order to avoid the plastic parts from deforming.
- ❖ Store the TOY in clean and dry place indoors. Do not expose to direct sunlight, rain, high temperature intervals, moisture or harsh weather!
- ❖ Always let the TOY to dry out fully before storing or using it, in order to avoid mold and rust.
- ❖ Contact your authorized dealer if consultation or repair is needed.

Materials used: plastic, metal.

DSXP021xxxx/ 220



Bulgaria, Plovdiv, Str. Golyamokonarsko shosse № 1

www.chipolino.com